
ZIERICK MANUFACTURING CORPORATION

131 Radio Circle, Mount Kisco, New York 10549 - (914) 666-2911 - FAX (914) 666-0216

Engineered Interconnection Solutions

-Since 1919-



Zierick Printed Circuit Board Terminal

Insertion Hand Tools

Zierick's printed circuit board terminal insertion hand tools offer a simple, reliable and repeatable method for performing press fit and splay mounted terminal assemblies. It is especially economical for low volume, short run and prototype applications. Zierick's insertion hand tools incorporate interchangeable components. A single hand tool can be used for several terminal insertion applications. Hand tools are available for all standard PCB mountable quick disconnect male and female terminals. Special tools can be provided for special applications.

Where increased application flexibility is required, hand tools may be incorporated with manually or automatically operated presses. The Insertion Tool allows for terminal application by press fit, and also the much preferred splay mounting.


Zierick hand tools are available for printed circuit board mounted .110", .187", .205" and .250" horizontal and vertical Quick Disconnect terminals, for .110", .187", .250" vertical Quick Disconnect receptacles, for Test Point Terminals and for .205" x. .025" vertical automotive Blade Fuse receptacles. Lower board support application tool dies are available for single or dual leg splay mounting requirements.


Insertion Tool with Splaying Anvil

The Insertion tool can easily be installed on almost any type of press machine. Zierick manufacturing suggests that this is done to provide for splaying of the terminal. When terminals are splayed, they are locked into place, improving reliability, preventing part removal and rotation, even with mounting hole tolerances as large as \pm .004".


The insertion Tool body is removed, and installed onto the press. The Anvil is mounted and aligned, so the terminal may be splayed. The Quick Disconnect is then placed in the "nest" of the Insertion Tool, and the P.C. Board is aligned with the terminal. The downward motion of the press inserts the terminal through the P.C. Board, causing the legs to spread or splay (shown at right). The Press is then pulled up, and the Quick Disconnect is permanently inserted into the P.C. Board. This type of insertion is ideal for those who wish high quality splayed insertions, but due to low volume an automated insertion machine would be impractical.


At higher volumes, we recommend Zierick model 9700, and 9700 XY automated terminal insertion machines.





Zierick Printed Circuit Board Terminal Insertion





ITEM PART NUMB	
TAKT NOND	ER

ZPT81-A

90-102-0300

90-101-0300

90-112-1375

Hand Tool (all vertical terminals)
Splay Anvil (30° - standard)*
Splay Anvil (60°)*
Anvil Holder (Base)*

Instructions for Insertion Tools ZPT81-A & ZPT92

ZPT81-A:


This Insertion Tool is Factory Assembled to accommodate Tab Part Number 836 (.250" x .032" Tab). For other Tab or Quick Disconnect sizes, refer to the 'POSITIONER PLATE SELECTION TABLE'.





ZPT92:

This Insertion Tool is Factory Assembled to accommodate Tab Part Number 901 (.250-90 Degrees x .032"). For other Tab or Quick Connect sizes, refer to the 'Positioner Plate Selection Table'.



To Change The Positioner Plate:

- 1. Remove the two Security Screws, the Retainer Plate and the Detent Plate.
- 2. Place the desired Positioner Plate onto the Tool Holder, with the Correct Terminal sized opening toward the front of the Tool Holder.
- 3. Replace the Detent Plate and the Retainer Plate.
- 4. Replace the two security screws, but do not tighten them.
- 5. Hold the Tool Assembly vertically downward against a flat surface, to align the inserted parts.
- 6. While in this position, tighten the two security Screws.
- 7. The Insertion Tool is now ready for use.

Positioner Plate Selector Table

Tool Type	PC Terminal Part Number	Tab Size and Type	Positioner Plate Number
ZPT81-A	836	.250	91-804-0190
	906	Male	
	1021		
ZPT81-A	894	.187	91-804-0190
	895	Male	
	1024		
	1027		
ZPT81-A	892	.205	91-805-0115
	893	Male	
ZPT81-A	834	.110	91-805-0115
	835	Male	
	1032		
	1033		
ZPT81-A	1022	.250	91-806-0238
	1037	Female	
	1040		
ZPT81-A	1025	.187	91-806-0238
	1026	Female	
ZPT92	901	.250 x 90Deg Male	91-853-0800
ZPT92	956	.187 x 90 Deg	91-853-0570
<u> </u>	957	Male	31-000-0070
ZPT92	986	.187 x 90 Deg	91-853-0800
		Male	0.000 0000
ZPT92	948	.110 x 90 Deg	91-853-0535
		Male	

Zierick Part Numbers

Application		Гаb	Receptacle		Insertion
Size	Standard	Stable-Lok	Standard	Stable-Lok	Tool
.110" x .020"	834	1063	-	-	ZPT81-A
.110" x .032"	835	1064	-	-	ZPT81-A
.187" x .020"	895	1027	-	1026 :	ZPT81-A
.187" x .032"	894	1024 : 1042	-	1025 :	ZPT81-A
.205" x .020"	893	-	-	-	ZPT81-A
.205" x .025"	-	-	-	1040	ZPT81-A
.205" x .032"	892	1065	-	-	ZPT81-A
.250" x .032"	836 : 906 972 : 953 953-MOD	1021 : 1041 1045 : 1057 1060 : 1061	-	1022 : 1037	ZPT81-A
.110" x .020"	949	-	-	-	ZPT92-110
.110" x .032"	948	-	-	-	ZPT92-110
.187" x .020	956	-	-	-	ZPT92-187
.187" x .032"	957	-	-	-	ZPT92-187
.250" x .032"	901	-	-	-	ZPT92-250
.120" x .020"	1032	1058	-	-	ZPT81-A
.120" x .032"	1033	1059	-	-	ZPT81-A